

AriScope – ARINC 429 Interface

Description

AriScope is an **ARINC 429** Bluetooth® interface for an Android Smartphone. It enables the acquisition and analysis of each received bit / label at both **High Speed** and **Low Speed** in **real time**.

The associated **AriScope** Android application decodes and displays each label with refresh rates, detailed information in “engineering” format (with label description file) and an **oscillogram** of a selected label (SDI as SDI or SDI as DATA).

AriScope is also able to record the whole activity of the line into a text file that can be sent immediately by e-mail from the application.

The battery powered device has a small size and is very simple to use (no cable). With the provided 18650 lithium battery, the runtime is over **50 hours** (2 years in standby).

Features

Interface with AriScope

- Banana plugs (2mm) for the ARINC 429 line:
 - o Hot point: yellow plug.
 - o Cold point: green plug.
- Bluetooth® 3.0 interface with the Smartphone.
- One green LED (device status).

Power Management

The electronic board is always powered by the battery.

There is no button on the **AriScope** device. An ARINC 429 line with at least one label wakes it up from sleep. Another way is to disconnect and reconnect the battery.

The blinking frequency of the LED indicates if the device is connected to the smartphone via Bluetooth®:

- **2 Hz** blinking frequency: device not connected.
- **1 Hz** blinking frequency: device connected.

If **AriScope** is not connected to the smartphone and no label is received, it will go to sleep after **2 minutes**, the LED is then switched OFF. The battery lasts more than **2 years** in this mode.

Specifications

- Included battery: 18650 lithium cell
- Maximum line level: $\pm 35V$
- Line input impedance: 12 k Ω
- Line input high threshold: $\pm 1.4V$
- Bluetooth® RF power: 4 dBm
- Product size: 87mm - 30mm - 23mm
- Weight (with battery): 79g
- Temperature range: 0°C – 60°C



Android Application

Download

The AriScope application is freely available here:

[MEONYS AriScope Android Application](#)

The installation is automatic and creates a shortcut on the smartphone main page:



[AriScope Application Information](#)

Device Connection

Before using the application for the first time, **AriScope** needs to be paired with the smartphone. The Android Bluetooth® settings can be accessed from the application by clicking on “NO DEVICES” label, then “SETTINGS”. **AriScope** device has to be powered up to allow pairing (see “Power Management”).

If a Bluetooth® password is asked, enter “0000”.

When going back to the application, the device that has just been paired is visible with its serial number. It has to be selected before going back to the **Home** page.

Home Page

The **Home** page displays in real time the list of received labels and the corresponding refresh rates, the total number of labels, the detected line speed (HS or LS) and device information (serial number, connection status and battery charge).

The **label description file** (txt or xml format) is selectable by clicking on the “LABEL [select description]” button. To get a description file as an example, visit the product page:

www.meonys.com/en/arinc-429-bluetooth-analyser/

S/N: FSJ88 		12 LABELS
CONNECTED		HS
LABEL [select description]		Hz
L076_00		4,9
L110_00		4,9
L111_00		4,9
L112_00		4,9
L112_01		4,9
L112_10		4,9
L112_11		4,9
L150_00		0,9
L260_00		4,9
L314_00		4,9
L324_00		4,9
L325_00		4,9
L326_00		4,9
L327_00		4,9
L330_00		4,9

Home Page

S/N: FSJ88 		12 LABELS
CONNECTED		HS
LABEL [select description]		Hz
L076_DD_L076_GPS_ALTITUDE		4,9
L110_DD_L110_GPS_LATITUDE		4,9
L111_DD_L111_GPS_LONGITUDE		4,9
L112_00_L112_01_L112_GPS_GND_SP		4,9
L112_01		4,9
L112_10		4,9
L112_11		4,9
L150	SELECT DIRECTORY	0,9
L260	SELECT DESCRIPTION FILE	4,9
L314	EECU_augmented.xml ☐	4,9
L324	AriStimGen_descFile_sample.txt ☐	4,9
L325	AriStim_gene_05-08-2025-14h00m08s.xml ☐	4,9
L326	AriStim.txt ☒	4,9
L327		4,9
L330_00_IR_YAW_RATE		4,9

Loading label description file

Label Page

When clicking on a label in the Home page, the **Label page** is displayed, showing information of the selected label:


S/N: FSJ88 	CONNECTED	HS	LABEL 112
L112_00_GPS_GND_SPD			(4,9 Hz)
GPS_GROUND_SPEED : 10 knot			
SSM : 11 NO			
Parity : 0			
L112_01			(4,9 Hz)
Data : 0 0000 0000 0001 0100 00			
SSM : 11			
Parity : 1			
L112_10			(4,9 Hz)
Data : 0 0000 0000 0001 0100 00			
SSM : 11			
Parity : 1			
L112_11			(4,9 Hz)
Data : 0 0000 0000 0001 0100 00			
SSM : 11			
Parity : 1			

Label Page

Raw data information is displayed, with both “SDI as SDI” and “SDI as DATA” representations. If a description file was selected, data is displayed in engineering format.

Oscilloscope Page

From the Label page, clicking on a specific SDI or clicking on the “SDI as Data” version of the label launches the **Oscilloscope page**:



Oscilloscope Page


This page displays in real-time the analog acquisition of the selected label and SDI at **1.1 MSPS in HS** and **137.5 KSPS in LS**.

The analog data is automatically synchronized and aligned to the digital version of the label. Colors and Column headers ease data interpretation.

The page is for example useful to determine if the ARINC line has too many receivers connected (too low impedance which reduces peak-to-peak voltage).

Recording Page

From the Home page, the user may access the **Record page** by clicking on the top left blue button (red when recording):




Recording Page

This page enables the user to record the whole ARINC line into a text file that can be sent by e-mail immediately after recording.

Clicking on one of the blue buttons starts recording. The labels are still decoded and a precise time stamp (20ns) is associated with each label.

Clicking again on the same button (now red) stops recording. A new file (with current date and time) is generated and displayed in the file list. The user may delete or share it by e-mail. The last entered e-mail address is saved.

The generated text file which is attached to the e-mail is easy to use (easy import in Excel for example):



The AriScope recorded files are also placed under "/AriScope/AriScopeRecordings" Android folder and may be retrieved by USB.

Warnings

This product shall only be used with the provided battery. The use of incompatible battery may affect compliance or may result in damage to the product and invalidate the warranty.

The provided battery shall only be charged with the provided Lithium-Ion charger. The use of incompatible battery charger may affect compliance or may result in damage to the battery and invalidate the warranty.

To avoid malfunction or damage to your **AriScope** product please observe the following:

- Do not expose to water or moisture.
- Do not expose to heat from any source; **AriScope** is designed for reliable operation at the specified temperatures.
- Care must be taken when handling to avoid mechanical or electrical damage to the product and connectors.